

C-Bus 2 C-Touch Colour Touch Screen Nail Bracket 5000CTCNA

Installation Instructions

The C-Touch Colour Nail Bracket (part number 5000CTCNA) provides a convenient means of mounting the C-Touch Colour Touch Screen. The nail bracket (illustrated in Figure 1) is used where it is practical to nail or screw the nail bracket into a wall frame.




Figure 1 - Nail Bracket

Overall External Dimensions (mm)
Width - 285
Height - 215
Depth - 47

To mount the nail bracket

- 1) Place the bracket against a beam of the wall frame.
- 2) Position flush with beams and frame towards front.
- 3) Nail the bracket into the frame. Alternatively, mark and drill the holes, then screw the bracket into the frame.
- 4) Feed the cables through to the nail bracket. The use of conduit is recommended. Refer to Figure 2. The number and positioning of cables will vary depending on the particular installation.




Figure 2 - Nail Bracket Cabling

Internal Cutout Dimensions (mm)
Width - 205
Height - 126

Schneider Electric (Australia) Pty Ltd

Contact us: clipsal.com/feedback

National Customer Care Enquiries:

Tel 1300 2025 25

Fax 1300 2025 56



clipsal.com

Schneider Electric (Australia) Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© 2014 Schneider Electric. All Rights Reserved.
Trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.